Golf/Vento

Current Flow Diagram

No. 74 / 1


Edition 02.1994

Front window lifter

From January 1994

Position of relays:

For alternatives to relay and fuse positions as well as multi-pin connector wiring - see "Fitting locations" section.




Fuse colours
- 30 A - green
- 25 A - white
- 20 A - yellow
- 15 A - blue
- 10 A - red

Golf/Vento

Current Flow Diagram

No. 74 / 2



ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = purple
vi = purple
ge = yellow
or = orange
rs = pink


Window lifter switch in driver's door, control unit and motor for lifter front left

E40	-	Front left electric window switch
E81	-	Window lifter switch, front right (in driver's door)
F4	-	Reversing light switch
F59	-	Central locking switch (driver's side)
J295	-	Electric window control unit, front left
L53	-	Window switch light bulb
S43	-	Window lifter thermo-fuse
T1	-	Single connector, behind relay plate
T32	-	32-pin connector, on lower part of left A-pillar
T32a	-	32-pin connector, on lower part of right A-pillar
V14	-	Window lifter motor, front left
44	-	Earth point, lower part of left A-pillar
205	-	Earth connection, in door wiring harness - driver's side
Q1	-	Positive (+) connection (30), in electric window wiring harness
Q13	-	Positive (+) connection -1- (15), in electric window wiring harness
Q45	-	Connection (convenience), in electric window wiring harness
R10	-	Positive (+) connection -1- (30), in door wiring harness - driver's side
R13	-	Positive (+) connection -4- (15), in door wiring harness - driver's side
R14	-	Connection -1- (open), in door wiring harness, driver's side
R15	-	Connection -2- (closed), in door wiring harness, driver's side

Golf/Vento

Current Flow Diagram

No. 74 / 3



ws = white
sw = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = purple
vi = purple
ge = yellow
or = orange
rs = pink

Window lifter switch in front passenger's door, control unit and motor for lifter front right

- E41 - Front right electric window switch
- F2 - Front left door contact switch
- J245 - Sliding sunroof adjustment control unit
- J296 - Electric window control unit, front right
- K - Dash panel insert
- K10 - Heated rear window warning lamp
- L9 - Lighting switch light bulb
- L53 - Window switch light bulb
- T1a - Single connector, behind relay plate
- T1c - Single connector, behind relay plate
- T5f - 5-pin connector, above the relay plate
- T6 - 6-pin connector, near interior light
- T28 - 28-pin connector, on dash panel insert
- T32 - 32-pin connector, on lower part of left A-pillar
- T32a - 32-pin connector, on lower part of right A-pillar
- TV8 - Terminal 58b junction box, above the relay plate
- V15 - Window lifter motor, front right
- 44 - Earth point, lower part of left A-pillar
- 206 - Earth connection, in door wiring harness - driver's side
- A11 - Positive (+) connection (55b), in wiring harness for instruments
- Q1 - Positive (+) connection (30), in electric window wiring harness
- Q20 - Connection -1- (door contact switch), in window wiring harness
- Q38 - Positive (+) connection (58b) -1-, in electric window wiring harness
- Q45 - Connection (convenience), in electric window wiring harness
- R16 - Positive (+) connection -1- (30), in door wiring harness - front passenger's side